



projects and ideas!

& World of Wonder & Tote



SIDE

Finished Size: 13 $\frac{1}{2}$ in x 17 $\frac{1}{2}$ in (34.29 cm x 44.45 cm)

Fabric Needed

3 Wishes® World of Wonder Collection

- 1 yd Panel (18682-PNL-CTN-D)
- ¾ yd Bubbles (18687 BLU-CTN-D
- ¼ yd Wings (18691-MLT-CTN-D)

Additional Supplies Needed:

- 5% yd Fusible fleece
- Sewing thread
- Quilting and sewing supplies
- Even-feed foot (optional for quilting)

Before You Begin

Read all instructions before beginning project. Do not pre-wash fabrics. Press fabrics with a dry iron on cotton setting before cutting. Use a $\frac{1}{2}$ in (1.27 cm) seam allowance and sew fabrics with right sides together (RST) unless otherwise noted. Press seams in the direction of the arrows. wof = width of fabric

Note: A printed panel may become slightly skewed during the finishing process. Check if panel is square before cutting by folding the panel so selvages meet. If all edges do not meet, pull firmly from corner to corner until the edges meet. Continue until all corners are square.

Cutting

Use a rotary cutter and acrylic ruler to cut the number of pieces from each fabric listed below.



4 in x wof			
YAR ZYAR ZYAR ZYARZ			
Wings (18691-MLT-CTN-D) ½ vd (9 in x wof / 22 86 cm x 106 68 cm)			

Wings (18691-MLT-CTN-D) ¼ yd (9 in x wof / 22.86 cm x 106.68 cm) Cut 1 - 4 in (10.16 cm) x wof for Strap

14 ½ in x 18 ½ in	

Fusible Fleece % yd (22.5 in x wof / 57.15 cm x 106.68 cm) Cut 2 - 14 ½ in x 18 ½ in (36.83 cm x 46.99 cm)

World of Wonder Panel (18682-PNL-CTN-D) 1 yd (36 in x 42 in / 91.44 cm x 106.68 cm) Fussy Cut 2 - 14 ½ in x 18 ½ in (36.83 cm x 46.99 cm) for Tote Bag



Bubbles (18687-BLU-CTN-D) 3 yd (27 in x wof / 68.58 cm x 106.68 cm) Cut 2 - 14 ½ in x 18 ½ in (36.83 cm x 46.99 cm) for Bag Lining Cut 2 - 5 in x 14 ½ in (12.7 cm x 36.83 cm) for Pocket & Pocket Lining

Sewing

- 1. Follow the manufacturer's instructions to fuse the fleece to the **wrong** side of Bag Side1 and Side 2 rectangles14 ½ in x 18 ½ in (36.83 cm x 46.99 cm).
- 2. Quilt around the printed images as desired. Pin the Bag Sides RST along the side and bottom edges; sew.
- 3. To box the bottom, bring the center bottom seam to a side seam RST. Mark 2 in (5.08 cm) from the point and sew from edge to edge. Trim the point to a ½ in (12.7 mm) seam (Dia. A). Repeat for the other side. Turn Bag right side out.



4. To make the Strap, fold the Wings strip 4" x 42" (10.16 cm x 106.68 cm) in half lengthwise and press to crease. Refer to Diagram B to open the strip and fold each long edge to the center crease; press. Fold the strip in half again so folded edges meet; press. Topstitch close to the long edges to make the Wings Strap.



- 5. On the right side of the Bag, pin the ends of the Strap centered over each side seam with cut edges even; sew ½ in (3.18 mm) from the edge (Dia. C). **Note:** Check that Strap is not twisted before sewing.
- 6. Pin the Bubbles Pocket and Pocket Lining 5 in x 14 ½ in (12.7 cm x 36.83 cm) pieces RST and sew along the top and bottom edges. Turn the Pocket right side out through a side opening; press and topstitch close to all edges.
- 7. On the right side of a Bubbles Lining piece 14 ½ in x 18 ½ in (36.83 cm x 46.99 cm) measure down 5 in (12.7 cm) from the top edge and make a mark at each side edge and also in the center (Dia. D).



Dia. D Bubbles Bag Lining



- 8. Place the top edge of the Pocket along the 5 in (12.7 cm) marks and pin around the edges; sew close to the side and bottom edges only.
- 9. Measure 5 ¼ in (13.34 cm) from each side edge of the pocket and draw a line from the top to the bottom edge. Sew ¼ in (6.35 mm) along each side of the drawn line to create three pockets (Dia. E).





- 10. Pin the Bubbles Lining pieces 14 ½ in x 18 ½ in (36.83 cm x 46.99 cm) RST with edges even. Sew around the side and bottom edges leaving a 5" (12.7 cm) opening in the bottom edge (Dia. F); press seams open. Refer to Step 3 to box the bottom edges. *Note: Do not turn Lining right side out.*
- 11. Place the Bag into the Lining RST with side seams and top edges matching; pin along the top edge and sew (Dia. G).
- 12. Turn the Bag right side out through the opening in the Lining; hand stitch opening closed.
- 13. Press and topstitch close to the top edge.



5 in (12.7 cm) Opening







Finished Care Instructions

Machine wash in cold water; gentle cycle. Do not bleach. Hang to dry or tumble dry low.